

Installation Instruction for The Fire Hydrant Spa Series of Shower Heads and Handhelds.

Tools which are needed: Pliers and a cloth to put between piers and shower head

1. Remove the old Shower head

- a. Take your protective washcloth and turn it left (counter clockwise).
- b. Once the shower head starts to turn please you figure pressure to turn the shower head until it comes off.

2. Install the new shower head or handheld bracket (for a handheld shower head)

- a. TURN IT TO THE RIGHT after applying Teflon tape and the rubber washer which are included
- b. Finger tighten the shower head or bracket until it is snug. It should take just a little turn, with your pliers. 1/8 of a turn to snug it tight to ensure a watertight seal. Please be careful and not too tight.

Please, do not hesitate to email us at info@take-a-shower.com with any questions, problems or broken parts.

Thank you, customer service